



22BCB1181 amplifier circuit board.

Standard load cell amplifier. Used for load pins and links.
Part # 33L0017 with mounting plate as shown here.

Part # 33L0018 is without the mounting plate. Used for line rider style dynamometers.